

STEP 7







Look for these and other great kits from amt POLAR LIGHTS mpc


POL881
Deluxe Edition
Batmobile™




MPC752
General Lee



AMT646
Munsters Koach



AMT657
Dragula



For more information, visit: round2models.com
visit our blog at: collectormodel.com

amt GHOSTBUSTERS™

A750-100

ECTO-1A

1/25 SCALE MODEL KIT



Model professionally assembled and finished by Bruce Pearce

ASSEMBLY MANUAL

ECTO-1A INFORMATION

WHAT COULD BE MORE APPROPRIATE FOR CHASING GHOSTS THAN A BLOCK-LONG '59 CADILLAC AMBULANCE, SPECTACULARLY OUTFITTED WITH ECTOPLASMIC SURVEILLANCE, DETECTION AND STORAGE EQUIPMENT FOR THE ETHERIAL BOGIES? PLUS, ENOUGH FLASHING LIGHTS TO LIGHT UP A SMALL TOWN? WHY, NOTHING ELSE EVEN COMES CLOSE - IT IS THE APPROPRIATE VEHICLE FOR THIS SPOOKY JOB. WHETHER IT'S SLIME IN YOUR REFRIGERATOR OR DANCING FURNITURE OR REAL GHOSTS IN YOUR TV, THE ECTO-1A IS ALWAYS ON CALL. AND WHO ARE YOU GONNA CALL? GHOSTBUSTERS, THAT'S WHO! THEY BELIEVE YOU.

SKILL NIVEAU NIVEL 2

Contents include: All plastic pieces to complete model, metal axles and pictorial instructions describing assembly. Paint and glue not included.

Round 2, LLC
4073 Meghan Beeler Ct.
South Bend, IN 46628

International Hobbycraft (UK) Ltd.
21 St. Thomas St.
Bristol BS1 6JS England

round2models.com collectormodel.com

TM & © 2012 Columbia Pictures Industries, Inc. All rights reserved. The Munsters is a copyright of Kayro-Vue Productions and a trademark of Universal Studios. Licensed by NBC Universal Television Consumer Products Group 2012. All Rights Reserved. Dragula is a registered trademark of Barris Kustom Inc. and is used under license to Round 2 LLC. Batmobile design by George Barris. GENERAL MOTORS Trademarks used under license to Round 2, LLC. AMT and Round 2 and design are trademarks of Round 2, LLC. © 2012 Round 2, LLC, South Bend, IN 46628 USA. Product and packaging designed in the USA. Made in China. All rights reserved. THE DUKES OF HAZZARD and all related characters and elements are trademarks of and © Warner Bros. Entertainment Inc. (s12) BATMAN™ and all related characters and elements are trademarks of and © DC Comics. (s12)

ASSEMBLY: Carefully study and understand the entire instruction sheet. Compare the parts in the box to the instruction sheet to be sure you have received all the parts required. Carefully remove parts from trees. Before cementing, "TEST FIT" parts together to insure proper location and alignment. Scrape paint and plating from surfaces to be cemented. Subassemblies and components should be painted before any parts are attached. Use only cement and paint made for styrene plastic.

PAINTING: Wash parts thoroughly with mild soap and water. Parting lines, glue joints, and sharp edges should be sanded or filled with filler putty designed for plastic. Apply a "primer" coat and allow to dry. Check parts for imperfections and repeat the procedure if necessary. Remove any lint or dust. Apply paint evenly, in several thin coats rather than one heavy coat. Allow each coat to thoroughly dry before the next is applied. Each coat should be carefully "wet sanded" using slightly damp No. 1200 sandpaper. Be careful not to remove any detail while sanding. Lightest colors should be painted first. Use frosted tape to mask off areas not to be painted. Remove tape after paint is dry to the touch. Use a very fine brush to touch up edges.

DECALS: See back of instruction sheet for proper application. Decals should to be added after applying a gloss coat. Apply a final clear coat after decals are dry.

RECOMMENDED TOOLS:

HOBBY KNIFE



Use a sharp hobby knife to remove parts from the trees. The knife may also be used to remove parting lines and flash.

TWEEZERS




Use tweezers to hold small parts during assembly, painting and when applying cement.

BRUSH




We recommend the use of liquid polystyrene cement. Apply with a fine brush. Use sparingly or a sloppy job will result.


STEP 1



STEP 2




STEP 3




STEP 4

NOTE: If you plan on building your kit as the ECTO-1, you will need to remove the six mounting brackets for the Electronic Sign (three each side) molded into the roof.



STEP 5



STEP 6

